

Volume 2 -- Issue 4

January, 1982

In This Issue...

| Hi-Res SCRN Funtion with Color | | • | • | • | | • | 2 |
|---|---|---|---|---|---|---|----|
| A Correction to "Step-Trace Utility " | | • | • | • | • | • | 6 |
| 6502 Relocator | • | • | • | • | • | • | 8 |
| A Review of THE INDEX | • | • | • | • | • | • | 12 |
| Serious Problem in Apple DOS | • | • | • | • | • | • | 13 |
| Putting S-C Assembler II on the Language Card | • | • | • | • | • | • | 15 |
| Handy EXEC Files | | | | | | | |
| 6500/1 One-Chip Microcomputer | • | • | • | • | • | • | 21 |
| A Review of FLASH!, an Integer BASIC Compiler | • | • | • | | | • | 22 |

Renew Now, the Price is Going Up

If you renew your subscription before March 1, 1982, you can renew at the current rate of \$12/year. Starting March 1st, the price will go up to \$15/year (2nd class mail in the USA). Subscriptions sent First Class Mail to USA, Canada, and Mexico will be \$18/year. Air Mail subscriptions to all other countries will be \$28/year. The price for back issues will be \$1.50 each (plus \$1.00 postage outside of USA, Canada, and Mexico).

S-C MACRO Assembler II is almost here!

I am committed to having a finished product by February 15th. This is what I have been calling Version 5.0, but I have decided to call it S-C MACRO Assembler II instead. Version 4.0 will still be sold at \$55. The MACRO version will be \$80. Owners of Version 4.0 can upgrade for only \$27.50. There will be an all new manual, rather than the current 2-part manual.

The MACRO Assembler includes macros (of course!), conditional assembly, EDIT, COPY, global string replacement, and many more new features. And it assembles even faster than version 4.0!

Hi-Res SCRN Function with Color......David Doudna

I am a 15-year-old living in St. Louis, Missouri. While looking through the back issues of Apple Assembly Line, I found "Hi-Res SCRN Function for Applesoft" (May, 1981 issue). I noticed the routine only returned a 0 or 1, and you challenged readers to write one to return a color value 0-7. Well, I did it. My version is not interfaced to Applesoft; that is an exercise for the reader! (I use the Programmer's Aid ROM with FORTH.)

I am not going to explain how hi-res colors work, beyond the facts that two adjacent dots are white; the upper bit in each byte of the hi-res screen adds 4 to the color value; an isolated bit is color 1 or 2 (or 5 or 6) depending on the X-position. If you want to understand my program, you should study more about hi-res plotting first.

A word about the color value.... In Applesoft you specify color value with a number from 0 to 7. The Programmer's Aid ROM uses color values of 0, 42, 85, 127, 128, 170, 213, and 255. My program returns both numbers for the color: the 0-7 index in HCOLOR, and the P.A.ROM color value in COLOR.BYTE.

Lines 1060-1140 define the variables used; these are in the same locations as those used by the Programmer's Aid ROM. If you want to modify the program to work with Applesoft, be sure to put these variables in the correct locations. Two more variables are defined at lines 2120,2130.

Lines 1160-1180 pick up the X- and Y-coordinates. I assume you have stored the coordinates here before calling HSCRN. Lines 1190-1390 calculate the base address for the particular horizontal line your point is on. This code is just copied out of P.A.ROM. Lines 1410-1530 divide the X-coordinate by 7 to get the byte offset on the line. The quotient is left in the Y-register. The remainder is used to pick up a bit mask to select the particular bit within the byte.

Lines 1540-1650 make the first color check. The high-order bit of the byte (half-dot shift control). If the bit specified = zero, the color is black. If it = one, the color depends on whether either neighbor of this dot = one. If neither neighbor = one, the color depends on whether this dot is in an even or odd column. If the color is not black, I put I or 2 in the X-register to indicate the color it will be if it is not white.

Lines 1660-1790 check the neighbor bit on the left to see if it = one. Notice that there are several special cases. First, the left-neighbor might be in the same byte. Second, it might be in the byte to the left of this one. Third, there might not be a byte to the left of this one.

Lines 1800-1920 check the neighbor bit on the right. The same kind of special cases exist here, and they are handled the same way.

Line 1940 sets X = 3 for white color. Line 1960 gets the color

value in the A-register. All paths merge at line 1980, with the color index 0-3 in the A-register. All that remains is to add 4 if the half-dot shift control = 1 (Lines 1980-2010.

Lines 2020-2060 convert the color index to a color byte (by simple table-lookup), and return. Line 2100 is the table of color values.

Here is a table of colors (their names, index numbers, and P.A.ROM numbers):

| | | Colo | r Byt | e Value |
|---------------------|-------|------------|-------|----------|
| Color | Index | Hex | Dec | Binary |
| | | | | |
| BLACK | 0 | 00 | 0 | 00000000 |
| GREEN | 1 | 2A | 42 | 00101010 |
| VIOLET | 2 | 55 | 85 | 01010101 |
| WHITE | 3 | 7 F | 127 | 01111111 |
| BLAC ^v 2 | 4 | 80 | 128 | 10000000 |
| ORANGE | 5 | AA | 170 | 10101010 |
| BLUE | 6 | D5 | 213 | 11010101 |
| WHITE2 | 7 | FF | 255 | 11111111 |

The program works with either page 1 or page 2 of Hi-Res. Set HPAGE to \$20 for page 1, or \$40 for page 2.

To call this program from Integer BASIC, you would first POKE the X- and Y-coordinates, then CALL the program, and then PEEK the color value. From assembly language, set up the coordinates and JSR HSCRN. The color index is returned in the X-register, and the color byte value in the A-register.

[Program and article modified somewhat by the editor]

| | 1000 * | | |
|--|------------------------------------|--|--|
| | 1010 * 1020 * | HI-RES SCRN | FUNCTION WITH COLOR |
| | 1030 • 1040 • | NOVEMBER 30. | DNA, FERGUSON, MISSOURI 1981 |
| 0026- 0027- | 1050 * 1060 HBASL 1070 HBASH | .EQ \$26 .EQ \$27 | BASE ADDRESS |
| 0030- | 1080 HMASK | .EQ \$30 | BIT MASK |
| 0320- 0321- | 1100 XOL | .EQ \$320 | X-COORDINATE |
| 0322- 0324- | 1120 YO | .EQ \$320 .EQ \$321 .EQ \$322 .BYTE .EQ \$326 | Y-COORDINATE |
| 0326- | 1140 HPAGE | .EQ \$326 | HI-RES PAGE (\$20 OR \$40) |
| 0800- AD 22 03 0803- AE 20 03 0806- AC 21 03 0809- 48 | 1160 HSCRN | LDA YO LDX XOL | GET (A)=Y-COORDINATE GET (Y,X)=X-COORD. |
| 0806- AC 21 03 | 1180 | LDY XOH | del (1,x)-x-coorb. |
| 0809- 48 | 1190 | PHA | Y-COORD BITS LABELED ABCDEFGH |
| 080A- 29 CO | 1200 | AND #\$CO | CALCULATE BASE ADDRESS FOR Y-COORD |
| 080C- 85 26 080E- 4A | 1210 | STA HBASL | IN HBASL, HBASH FOR |
| 080F- 4A | 1220 | LSR LSR | ACCESSING SCREEN MEMORY VIA (HBASL), Y |
| 0810 05 26 | 1230 1240 | ORA HBASL | HBASH = PPPFGHCD |
| 0812- 85 26 | 1250 | STA HBASL | HBASL = EABABOOO |
| 0814- 68 | 1260 | PLA | WHERE PPP=001 FOR \$2000-3FFF |
| 0812- 85 26 0814- 68 0815- 85 27 0817- 0A 0818- 0A | 1270 1280 | STA HBASH ASL | AND PPP=010 FOR \$4000-5FFF |
| 0818- 0A | 1290 | ASL | |
| 0819- OA | 1300 | ASL | |

| 081C- 0A 081D- 26 27 081F- 0A 0820- 66 26 | 1320 A 1330 R 1340 A 1350 R 1360 L 1370 A 1380 O 1380 S | ROL HBASH ASL ASL ROR HBASL LDA HBASL LDA HBASH AND #\$1F ORA HPAGE STA HBASH | |
|--|---|---|-----|
| 082B- 8A 082C- CO 00 082E- FO 05 0830- AO 23 0832- 69 04 | | TXA DIVIDE X-COORD BY 7 (7 DOTS PER BY: CPY #0 IS X-COORD > 255? BEQ .2 NO, ENTER SUBTRACTION LOOP LDY #35 YES: 256 = 7*36 + 4 CARRY WAS SET, SO ADDS 5 ALSO CLEARS CARRY, SO SBC #7 BELOW ACTUALLY SUBTRACTS 8 INY SBC #7 SUBTRACT 7 (OR 8 IF CARRY CLEAR) BCS .1 STILL MORE 7'S TAY BEMAINDER IS BIT POSITION | TE) |
| 083A - BD 9E 07 083D - 85 30 | 1520 L 1530 S | LDA MSKTBL-249,X STA HMASK | |
| 083F- B1 26 0841- 29 80 08 0843- B1 26 0848- 25 30 0844- F0 38 0844- F0 20 03 084F- A2 01 0851- 4A 0852- B0 01 0854- E8 | 1550 1570 1580 1590 A 1600 E 1620 L 1630 L 1640 E | LDA (HBASL),Y GET BYTE WHICH HAS OUR SPOT AND #\$80 ISOLATE HALF-DOT SHIFT BIT STA HIBIT LDA (HBASL),Y GET BYTE AGAIN AND HMASK ISOLATE OUR SPOT BEQ .9 COLOR IS BLACK (0 OR 4) LDA XOL NOT BLACK LDX #1 LSR ODD OR EVEN X-COORD.? BCS .3 ODD, COLOR=1 OR 5 INX EVEN, COLOR=2 OR 6 | |
| 0855- A5 30 0857- 4A 0858- 90 0D 085A- 98 085B- F0 0E 085D- 88 085E- B1 26 | 1670 .3 I 1680 I 1690 E 1700 I 1710 E 1720 I | LDA HMASK LOOK AT NEIGHBOR BIT ON LEFT LSR BITS ARE IN BYTE BACKWARDS BCC .4 NEIGHBOR IN SAME BYTE TYA NEIGHBOR IN DIFFERENT BYTE BEQ .5 NO BYTE LEFT OF THIS ONE DEY LDA (HBASL),Y | |

WHAT, ANOTHER IMPROVEMENT ?

Yes! DISASM The Intelligent Disassembler For The APPLE Has Been Enhanced With More Features Making It One Of The Most Powerful Utilities Of Its Kind. DISASM Converts 6502 Machine Code Into Meaningful, Symbolic Source. The Resultant Text File Can Be Used With Any Of The Most Popular Assemblers. DISASM Is An Invaluable Aid For Understanding And Modifying Machine Language Programs. Here Are The Specs:

DISASM (VERSION 2.2)

* Selectable output formats are directly compatable with DOS ToolKit, LISA and S-C (4.0) Assemblers. * 100% machine language for fast operation. * Auto-prompting for easy use. * Operates on either the APPLE II or APPLE II Plus. * Labels automatically assigned as Pg Zero, External or Internal. * Labels and addresses are sorted for user convenience. * ORIGIN and EGUATE pseudo-ops provided. * Source segmentation after JMP and RTS allows for easier reading and understanding. * No restriction on disassembled block length (other than ROM or Assembler limitations). * Correctly disassembles displaced object code (The program being disassembled doesn't have to reside in the memory space in which it executes). * User defined Label Name Table replaces arbitrary label assignments (External, Pg Zero and even Internal labels become more meaningful, e.g. JSR COUT, LDA HADTOP. The use of the Name Table is optional. * Monitor ROM Label Name Table is included with over 100 of the most commonly used subroutine labels. Label table SOURCE is also provided so you can extend and customize it to your own needs. * Multiple data tables with user defined format may be intermixed with instructions. * NEM ! A FULL Cross-Reference provides a complete table (to screen or printer) grouped by referenced address type. * NEM ! A SINGLE Cross-Reference feature searches through the object code for a single user—specified address.

DISASM (2.2) Program Diskette & User Manual: \$38.00 Upgrade Kit for previous purchasers of DISASM: \$12.50 All shipments within continental USA via First-Class mail Foreign Orders: Add \$3.00 for Air Mail

> RAK-WARE 41 Ralph Road West Orange NJ 07052

```
1740
1750
1760
1770
1780 .4
0860- 29
0862- D0
0864- C8
                                          AND #$40
BNE .7
                                                              WHITE
                                                              RESTORE Y
                                          INY
0865- D0
0867- 31
0869- D0
              04
                                          BNE
                                                               ... ALWAYS
                                                (HBASL),Y
                                          AND
                        1790
1800 •
                                          BNE
                                                              WHITE
086B- A5
              30
                        1810
                                          LDA HMASK
                                                              LOOK AT NEIGHBOR BIT ON RIGHT
086D- 0A
086E- 10
                       1820
1830
1840
                                          ASL
                                          BPL .6
CPY #39
BCS .8
                                                              NEIGHBOR IS IN SAME BYTE
ALREADY AT RIGHT END?
YES, NOT WHITE THEN
086E- 10 0D
0870- C0 27
0872- B0 0F
0874- C8
0875- B1 06
0877- 29 01
0879- D0 06
087B- F0 06
087F- F0 02
                        1850
                                          INY
                       (HBASL).Y
                                          AND
                                                              WHITE
                                               (HBASL),Y
                                          BEQ
                                          AND
                                          BEQ
0881- A2 03
                              ÷7
                                          LDX #3
                                                              COLOR IS WHITE (3 OR 7)
                              .8
0883- 8A
                                          TXA
                                                             COLOR TO A-REG
0884-
0887-
0889-
0886-
0886-
0896-
0893-
0896-
                  08
              A6
                              .9
                                          BIT HIBIT
                                                              SEE IF HALF DOT SHIFT
         10
18
              Ö3
                                          BPL .10
                       2010
2020
2030
2040
2050
2060
         69
8D
              04
                                          ADC
                                               #4
                                                              YES
                               .10
              Ã7 08
                                               HCOLOR
                                          STA
         AA BD 80 60
                                                             USE COLOR # (0-7) TO GET COLOR BYTE
                                          TAX
              9E 08
                                               COLOR. TABLE, X
                                          LDA
                                          STA HCOLOR. BYTE
                  03
                                          RTS
                       2070
0897-
089A-
089D-
         01
08
40
              02 04
                       2080 MSKTBL .HS 01020408102040
089E- 00 2A
08A1- 7F 80
08A4- D5 FF
             2A
80
                       08A6-
                                                              COLOR INDEX 0-7
```

NEW UTILITY FOR THE S-C ASM

Do You Like Having Your Labels, Opcodes And Comments Lined Up For Readability, But Don't Want To Give Up Free Format Entry. Or Did You Set Your Tabs For 8 Char Labels And Found You Needed A Few Longer Ones? Now There's No Need To Manually Edit Just To Lineup Those Columns. SC.TAB Is A Source Formatting Utility For Use With The S-C Assembler (4.8). You Simply Specify The Column Numbers For Opcodes And Comments And SC.TAB Does The Rest. A Two-Pass Operation Insures You That There Are No Confilets Before Any Changes Are Actually Made. Should A Problem Arrise Then The Offending Line And The Tab Settings Are Displayed For Your Inspection. The User Can Limit Changes To Any Portion Of Source. SC.TAB Is Fast Since Its 188% Machine Language.

SC. TAB Program Diskette & User Manual: \$15.00

INTRODUCTORY OFFER!

For A Limited Time SC.TAB Is Available At A Special Introductory Price When Purchased With Both Of Our Other S-C Assembler Utilities.

* SC. XREF : Generates Label Cross Reference Tabels For Complete Source Documentation

* SC.6SR: A Global Search-And-Replace Eliminates Tedious Manual Renaming Of Labels

Normally, All Three Utilities Would Cost \$55.00. Buy Them Now And Save \$10.00

SC Utility Package: \$45.00

All shipments within continental USA via First-Class mail

Foreign Orders: Add \$3.00 for Air Mail

RAK-WARE 41 Ralph Road West Orange NJ 07052 A Correction to "Step-Trace Utility"....Bob Sander-Cederlof

"Step-Trace Utility", published in the July 1981 issue of AAL (pages 17-20), has a bug. Three or four of you ran into the problem and called me about it, but I was never able to duplicate the problem. Finally Bob Leedom managed to pinpoint the bug, and I found out how to fix it.

If you have used Step-Trace, you might have noticed that it sometimes will hang-up or go crazy after a relative branch instruction. The problem is that if the 6502 was in decimal mode, the calculations are all incorrect. This affects the branch target, and also messes up screen output. To fix it, insert the following line:

2095 CLD SELECT BINARY MODE

But how did the 6502 get into decimal mode, when I wasn't ever setting it? The contents of SAVE.P were random on initial start-up. Sometimes the contents managed to switch on decimal mode! Perhaps you should also insert the following two lines, to be certain of the initial status of the program you are tracing:

1455 LDA #0 CLEAR INITIAL STATUS 1456 STA SAVE.P

Future copies of Quarterly Disk #4 already have these two patches installed.

APPLE SeaFORTH

SeafORTH for the Apple computer with DOS 3.3 and at least 32K of RAM. Includes Disc I/O, Editor, Assembler, transcendental floating Point, high level source listing, and 150 pg. manual with complete source listing. SeafORTH is a consistant structured operating system providing the programmer with the tools to easily create programs from machine language to high level compiled applications. Edit- compile- executeedit cycle is measured in seconds, not minutes. Implemented as a true incremental compiler. SeafORTH generates machine code, not interpreted address lists. Direct threaded subroutine code implementation executes much faster than FIB style interpreted address versions. Hot for the novice progresser. Menual alone is \$25.66, disc and manual for only \$75.66. Send Check or Money Order tos

> TAU LAMBDA P.O. BOX 808 POULSBO, NASHINSTON 98370 (206) 598-4863

| S-C ASSEMBLER II Version 4.0\$55.00 Includes Manual, Diskette with Assembler and sample source programs, and Quick Reference Card. |
|--|
| Source code of Version 4.0 on disk\$95.00 Fully commented, easy to understand and modify to your own tastes. |
| Cross Assembler Patches for 6809\$20.00 Requires possession of Version 4.0. Enables you to develop programs for the Motorola 6809 CPU. (The MILL from Stellation, EXCEL-9 from ESD Laboratories, or the Radio Shack Color Computer.) |
| Cross Assembler for 6800\$22.50 Requires possession of Version 4.0. Enables you to develop programs for the Motorola 6800, 6801, and 6802 CPUs. |
| AAL Quarterly Diskseach \$15.00 Each disk contains all the source code from three issues of "Apple Assembly Line", to save you lots of typing and testing time. QD#1: Oct - Dec 1980 QD#4: Jul - Sep 1981 QD#2: Jan - Mar 1981 QD#5: Oct - Dec 1981 QD#3: Apr - Jun 1981 |
| Double Precision Floating Point for Applesoft\$50.00 Provides 21-digit precision for Applesoft programs. Includes subroutines for standard math functions. |
| Some Simple Integer BASIC Games\$10.00 Includes 4x4x4 tic-tac-toe, lo-res space war, lo-res jig-saw puzzle, and mastermind. |
| Blank Diskettespackage of 20 for \$50.00 Verbatim Datalife, with hub rings, no labels, in plain white jackets, in cellophane wrapper. |
| Lower-Case Display Encoder ROM\$25.00 Works only Revision level 7 Apples. Replaces the encoder ROM. Comes with instructions. |
| Diskette Mailing Protectors |
| Zip-Lock Bags (2-mil, 6"x9") |
| Books, Books, Books |

^{***} S-C SOFTWARE, P. O. BOX 280300, Dallas, TX 75228 ***
*** (214) 324-2050 We take Master Charge and VISA ***

Apple Assembly Line....January, 1982....Copyright (C) S-C SOFTWARE....Page 7

6502 Relocator......Bob Sander-Cederlof

Programs that are already assembled usually must be loaded at a specific memory address to execute properly. If you want to run it somewhere else, you have a problem. All the data references, JMP's, and JSR's will have to be examined to see if they need to be modified for the new location. If you don't have the source code, you can't re-assemble it. The other way, patching, can be quite a tedious operation!

Fortunately, way back in 1977, the WOZ (Steve Wozniak to you newcomers) wrote a program to do the work automatically. If you have the Programmer's Aid ROM then you have his RELOCATE program. You who have Apple II Plusses with the Language Card (also called 16K RAM card) can also use his program, because it is in the INTBASIC file along with Integer BASIC. (The latter group of people probably don't have the manual, though, because they didn't buy the ROM.)

I would like to see the RELOCATE program made more widely available, but it cannot be used as is unless you have Integer BASIC. Why? Because it uses SWEET-16 opcodes. RELOCATE also is itself tied to running at whatever location it is assembled for, so it can be a little trouble to find a place for it sometimes. By now you have probably guessed that I have recoded RELOCATE to solve both of these problems!

Paul Schlyter's article elsewhere in this issue of AAL shows RELOCATE put to good use. You can examine his instructions and learn most of what you need to know to use RELOCATE on your own programs. Basically, there are four steps:

- 1. Initialize. This sets up the control-Y monitor command. If RELOCATE is on a file, you do this with "BRUN RELOCATE".
- 2. Specify the program start and end addresses (where it now is in memory), and the new starting address (where you want it to be relocated to). This is done with the monitor command:

target<start.end^Y*

where "target" is the new starting address, and "start" and "end" are the addresses of the program where it is now.

"'Y" means "control-Y". The "*" after the control-Y signals RELOCATE that you are in step 2 rather than step 3 or 4.

3. Specify the FIRST block to be copied "as-is" or to be "relocated" to the destination area. This is done with the monitor command:

target<start.end^Y
or target<start.endM</pre>

where "target" is the starting address in the new area for this block, and "start" and "end" define the block itself. Note that there is no trailing asterisk this time. Use control-Y if you want this block relocated, or M if you want it copied as-is.

4. Specify the NEXT block to be copied as-is or relocated. You do this with the monitor command:

.end^Y

or

where the target and start addresses are assumed to immediately follow the previously handled block, and "end" specifies the end of this new block. Use control-Y to relocate the block, or M to copy it as-is.

Obviously, step 4 above is repeated until the whole program has been copied/relocated. For each block of your program that is to be copied as-is, with no modification at all, you use the "M" command; for each block to be relocated you use the "control-Y" command.

If you need more detailed instructions and explanation, I must refer you to the manual. The Programmer's Aid #1 Manual is sold at most computer stores separately from the ROM package. Pages 11-28 explain why and how to use RELOCATE, and pages 80 and 81 contain the assembly listing.

Now here is my new version, which can be BRUN anywhere you have 134 (\$86) bytes available. I have eliminated the SWEET-16 usage; this made the program slightly bigger, and a lot faster.

Lines 1260-1380 are the initialization code. They build the control-Y vector at \$3F8-3FA. A JMP opcode is stored at \$3F8; if you have DOS up this is redundant. but it won't hurt. Next I have to try to find myself. That is, where in memory am I (the program RELOCATE) located? JSR MON.RETURN (which is only an RTS instruction, so it comes right back without doing anything) puts the address of the third byte of the JSR instruction on the stack. Lines 1290-1370 use that address to compute the address of RELOC, and store it in \$3F9 and \$3FA.

When you type in a control-Y command, the monitor will now branch to RELOC at line 1400. Lines 1400-1430 look at the character after the control-Y in the command input buffer; if it is an asterisk, then you are trying to do step 2 above. If not, then you are on step 3 or 4. Lines 1440-1500 handle step 2, and lines 1510-1990 handle steps 3 and 4.

The part which used to be coded in SWEET-16 was lines 1690-1880. The SWEET-16 version took only 14 bytes, while the 6502 code takes 34 bytes. The 6502 version may take about 100 microseconds to execute, and the SWEET-16 version on the order of 1000 microseconds (for each instruction relocated).

Decision

Decision Systems P.O. Box 13006 Denton, TX 76203 817/382-6353

DIS-ASSEMBLER

DSA-DS dis-assembles Apple machine language programs into forms compatible with LISA, S-C ASSEMBLER (3.2 or 4.0), Apple's TOOL-KIT ASSEMBLER and others. DSA-DS dis-assembles instructions or Labels are generated for referenced locations within the machine language program.

\$25, Disk, Applesoft (32K, ROM or Language card)

OTHER PRODUCTS

ISAM-DS is an integrated set of Applesoft routines that gives indexed file capabilities to your BASIC programs. Retrieve by key, partial key or sequentially. Space from deleted records is automatically reused. Capabilities and performance that match products costing twice as much. \$50 Disk, Applesoft.

PBASIC-DS is a sophisticated preprocessor for structured BASIC. Use advanced logic constructs such as IF...ELSE..., CASE, SELECT, and many more. Develop programs for Integer or Applesoft. Enjoy the power of structured logic at a fraction of the cost of PASCAL.

\$35. Disk, Applesoft (48K, ROM or Language Card).

FORM-DS is a complete system for the definition of input and output froms. FORM-DS supplies the automatic checking of numeric input for acceptable range of values, automatic formatting of numeric output, and many more features.

\$25 Disk, Applesoft (32K, ROM or Language Card).

UTIL-DS is a set of routines for use with Applesoft to format numeric output, selectively clear variables (Applesoft's CLEAR gets everything), improve error handling, and interface machine language with Applesoft programs. Includes a special load routine for placing machine language routines underneath Applesoft programs. \$25 Disk, Applesoft.

SPEED-DS is a routine to modify the statement linkage in an Applesoft program to speed its execution. Improvements of 5-20% are common. As a bonus, SPEED-DS includes machine language routines to speed string handling and reduce the need for garbage clean-up. Author: Lee Meador.

\$15 Disk, Applesoft (32K, ROM or Language Card).

(Add \$4.00 for Foreign Mail)

*Apple II is a registered trademark of the Apple Computer Co.

```
1000
                                 1010
1020
1030
                                                           6502 RELOCATION SUBROUTINE
                                                          MAY BE LOADED ANYWHERE, AS IT IS SELF-RELOCATABLE
                                 1040
                                                          ADAPTED FROM SIMILAR PROGRAM IN PROGRAMMERS AID #1
ORIGINAL PROGRAM BY WOZ, 11-10-77
ADAPTED BY BOB SANDER-CEDERLOF, 12-30-81
                                 1050
                                 1060
                                 1070
                                                           (ELIMINATED USAGE OF SWEET-16)
                                          .
                                 1090
                                                                          $34
$2F
$F88E
$FCB4
$FF58
$0100
$0200
0034-
                                                                                      COMMAND BUFFER POINTER
# BYTES IN INSTRUCTION - 1
DISASSEMBLE (FIND LENGTH OF OPCODE)
                                 1100 MON.YSAV
1110 MON.LENGTH
                                                                   .EO
                                                                  .ĒÒ
                                 1120 MON.INSDS2
1130 MON.NXTA4
1140 MON.RETURN
1150 STACK
1160 INBUF
                                                                   POOCO
 F88E-
                                                                                                 UPDATE POINTERS, TEST FOR END
 FCB4-
FF58-
0100-
                                                                                                 SYSTEM STACK
                                           INBUF
                                                                                                 COMMAND INPUT BUFFER
 0200-
                                                                    .EQ
                                 1170 4-
1180 A1
1190 A2
1200 A4
1210 R1
                                                                  $3C,3D
$3E,3F
$42,03
$02,03
$04,05
$08,09
$0A,0B,0C
                                                          EEEEEE
003C-
003E-
0042-
                                 1200 A4
1210 R1
1220 R2
1230 R4
1240 INST
1250 =----
1260 START
0002-
 0008-
 000A-
                                                           ĒÒ
0800- A9
0802- 8D
                   4C
F8
58
                                                          LDA #$4C JI
STA $3F8 BI
JSR MON.RETURN
                                                                                      JMP OPCODE
BUILD CONTROL-Y VECTOR
                                 1270
 0805-
             20
                  58 FF 1280
1290 START1
1300
1310
00 01 1320
14 1330
F9 03 1340
01 01 1350
00 1360
FA 03 1370
1380
1380
1390 #-----
                                                                                                FIND OUT WHERE I AM FIRST
0808- BA
                                                          TSX
-0809
-A080
                                                          DEX
                                                                                      POINT AT LOW BYTE
                                                           SEC
                                                          SEC +1
LDA STACK,X LOW BYTE OF START1-1
ADC #RELOC-START1
STA $3F9
LDA STACK+1,X HIGH BYTE OF STAR
ADC /RELOC-START1
080B- BD
             69
8D
080E-
0810-
0813- BD
0816- 69
0818- 8D
                                                                                            HIGH BYTE OF START 1-1
             69
8D
60
                                                           STA
                                                                   $3FA
                                                           RTS
081C- A4
081E- B9
0821- C9
0823- D0
0825- E6
0827- A2
0829- B5
082B- 95
082B- CA
082E- 10
0830- 60
                                                         LDY MON.YSAV COMMAND BUFFER POINTER LDA INBUF,Y GET CHAR AFTER CONTROLIS IT ***?

BNE RÉLOC2 NO, RELOCATE A BLOCK LDX #7 COPY A1, A2, AND A4

LDA A1,X STA R1,X DEY
                   34
00 02
                                  400 RELOC
                                                                                      GET CHAR AFTER CONTROL-Y
IS IT "*"?
                                 1410
1420
1430
1440
1450
                   AA
OC
                                                                                      NO, RELOCATE A BLOCK
YES, GET BLOCK DEFINITION
COPY A1, A2, AND A4
                   34
07
30
02
                                          . 1
                                 1470
                                                          DEX
                                 1490
                                                           BPL
                                 1500
                                                           RTS
                                1500 RTS
1510 RELOC2 LDY
1520 RELOC2 LDY
1530 .1 LDA
1540 STA
1550 DEY
1560 BPL
1570 JSR
1580 LDX
1590 BEQ
1600 DEX
0831-
0833-
0835-
0838-
0838-
0838-
0840-
                   02
3C
0A
                                                                  #2
(A1),Y
INST,Y
                                                                                      COPY NEXT 3 BYTES FOR MY USE
             AO
             B1
             99
88
                          00
                   F8
8E F8
              10
                                                          JSR MON.INSDS2 GET LENGTH OF INSTRUCTION LDX MON.LENGTH 0=1 BYTE, 1=2 BYTES, 2=3 BYTES BEQ .3 1-BYTE OPCODE
             20
             A6
                    2F
31
             F0
 0842-
0843-
0845-
0847-
0848-
                                 1610
1620
1630
1640
                                                                                      3-BYTE OPCODE
2-BYTE OPCODE
SEE IF ZERO-PAGE MODE
NO (XO OR X2 OPCODE)
             DÖ
                    00
                                                           BNE
             A5
29
F0
                                                           LDA
                                                                  İŅŞŢ
                    ÕÃ
                    OD
                                                           AND #$OD
                    28
08
                                                           BEO
                                                           AND #$08
             29
                                 1650
1660
             DÓ
85
                    24
 084D-
                                                           BNE
                                                                                      NO (80-FF OPCODE)
 084F-
                    ōċ
                                 1670
1680
                                                           STA INST+2
                                                                                      CLEAR HIGH BYTE OF ADDRESS FIELD
0851-
0853-
0855-
0857-
0859-
0858-
085E-
                                 1690
1700
1710
1720
1730
1740
1750
            A5
C5
A5
E5
                    04
                                                           LDA R2
CMP INST+1
                                                                                       COMPARE ADDR TO END OF SOURCE BLOCK
                                           .2
                    ŌB
                                                           LDA R2+1
SBC INST+2
                    05
             90
38
                    ı 8
                                                                                       ADDR > SRCEND
                                                           BCC
                                                                    • 3
                                                           SEC
                                                                                       COMPARE ADDR TO BEGINNING OF SRC
             A5
E5
A8
                    0B
                                                           LDA
SBC
                                                                   INST+1
                    02
                                                                   R 1
0860-
0861-
0863-
0865-
                                 1770
1780
1790
1800
                                                           TAY
             A5
E5
90
                    0C
03
0C
                                                           LDA
SBC
                                                                   INST+2
                                                                  R1+1
                                                                    . 3
                                                                                      ADDR < SRCBEG
```

```
0867- AA
0868- 98
0869- 18
0864- 65 08
                              1810
1820
1830
1840
                                                      TAX
                                                      TYA
CLC
ADC R4
                                                                                ADDR = ADDR-SRCBEG+DESTBEG
086C- 85 0B
086E- 8A
086F- 65 09
0871- 85 0C
                              1850
                                                      STA INST+1
                              1860
                                                      TXA
                                                             R4+1
                                                      STA INST+2
                              1880
                              1890 --
0873- A2 00
0875- A0 00
0877- B5 0A
0879- 91 42
0878- E8
                              1900 .3
                                                      LDX #0
LDY #0
                                                                                COPY MODIFIED INSTRUCTION TO DESTINATION
                              1910
1910
1920
1930
1940
                                                      LDA INST,X
STA (A4),Y
                                                                                NEXT BYTE OF THIS INSTRUCTION
                                                      INX
0876- 20 B4 FC
087F- C6 2F
0881- 10 F4
0883- 90 AC
0885- 60
                              1950
1960
1970
                                                                                ADVANCE A1 AND A4, TEST FOR END THE TEST FOR END OF THIS INSTRUCTION MORE IN THIS INSTRUCTION END OF SOURCE BLOCK
                                                      JSR
DEC
                                                             MON.NXTA4
                                                             MON.LENGTH
                                                              RELOC2
```

A Review of THE INDEX......Bob Sander-Cederlof

THE INDEX is a new book that you can use. No doubt you subscribe to three or more magazines and newsletters, out of the 100 or so that are being published with information Apple owners want and need. Wouldn't you like a composite index that covered the best ones?

Bill Wallace an attorney in St. Louis, Missouri, has put together just such an index. His book compiles over 12000 articles, editorials, and columns from over 900 issues of personal computer magazines published during the last six years. Over 40 different magazines and newsletters are covered. I am honored that Bill has chosen to include both of my newsletters: Apple Assembly Line, and AppleGram.

Organized as a Key-Word in Context (KWIC) index, there are over 30000 entries. There are 92 pages of Apple-related articles, 160 pages covering other computers (Apple owners will be interested in the CP/M and 6502 sections), and over 200 pages of general articles. All the information necessary for obtaining copies and/or subscriptions of the various magazines and newsletters is also included.

Bill plans to publish a second edition later this year to include the issues published since the cutoff date of the first edition, as well as lots of additional publications that were not previously covered.

THE INDEX costs \$14.95, and is available from Missouri Indexing, Inc., P. O. Box 301, St. Ann, MO 63074. Bill is responsive to requests for group rates, if you can interest your local Apple club; call him at (314) 997-6470.

Serious Problem in Apple DOS.....Bob Sander-Cederlof

If you are trying to use the IRQ interrupt line for any purpose, and also DOS. you may have run across this problem before. Apparently at random, for no good reason, you may get the NO BUFFERS AVAILABLE message.

The reason is that both DOS and the IRQ interrupt code are trying to use the same page zero location: \$0045. DOS uses this location as part of a pointer address when looking for the next available buffer. (See the code at \$A2CB-A2CF and \$A764-A780.) DOS also uses \$0045 when printing the catalog (see \$ADB9, \$AE09, and \$AE53).

The IRQ interrupt code in the Apple Monitor ROM (at \$FA86) uses \$0045 to save the contents of the A-register. If an interrupt occurs while DOS is in the process of looking for a buffer, POW!

One solution is to turn off interrupts whenever DOS may be active, using the SEI opcode. A better solution would be quite difficult: look through all of DOS and modify every reference to \$0045 (or to \$0044 and \$0045 as a pair) to use some other location in page zero. A third possible solution for those who can do it is to modify the Apple Monitor ROM to use some other location to save the A-register.

In case you ARE using interrupts and DOS together, you should also know that RWTS does inhibit interrupts while it is active. After a call to RWTS is complete, the interrupt-inhibit status is restored to whatever it was before the call. Interrupts cannot be allowed during RWTS, because of the critical software timing code involved in reading and writing the disk.

APPLE 8-BIT 8-CHANNEL A/D SYSTEM

- ➤ 8-BIT RESOLUTION
- ➤ ON BOARD MEMORY-(Just peek at data)
- ➤ FAST CONVERSION (.078 ms per channel).
- ➤ ELIMINATES NEED TO WAIT FOR A/D CON-VERSION
- > A/D PROCESS TOTALLY TRANSPARENT TO APPLE.
- > FULL SCALE INPUTS CAN EASILY BE CHANGED BY USER.

APPLIED ENGINEERING'S A/D board is a breakthrough product for all APPLE owners giving real world data at a really affordable price. Diverse applications include monitoring of:

.....TEMPERATURE.....HUMIDITY.....WIND SPEED....WIND DIRECTION....
LIGHT INTENSITY....PRESSURE.....RPM....SOIL MOISTURE.....

CONTRIBUTED PROGRAMS ARE DISTRIBUTED FREE TO ALL A/D OWNERS IN OUR NEWSLETTER.

See your dealer or contact -

APPLIED ENGINEERING P.O. BOX 470301 DALLAS, TEXAS 75247



MASTER CHARGE & VISA WELCOME

(214) 492-2027

7:00 AM - 11:00 PM 7 DAYS A WEEK
APPLE PERIPHERALS ARE OUR ONLY BUSINESS

----- (C E E M A C)-----

THE VISUAL COMPOSITION SYSTEM

RELEASE 1.0 NOW AVAILABLE

\$40*

FIRE ORGAN

CEEMAC IS THE LANGUAGE OF FIRE ORGAN, WHICH WAS THE 1ST 'SOFT VISUAL ALBUM'.

A SYSTEM TO CREATE PERFORMANCE LEVEL ABSTRACT VISUALS TO ACCOMPANY MUSIC HAS ELUDED OUR GRASP FOR EONS. MY PERSONAL SEARCH HAS LED TO CEEMAC.

DESIGNED PRIMARILY TO SUPPORT THIS NEW ART FORM, CEEMAC PROVIDES A HIGHLY INTERACTIVE COMPOSING ENVIRONMENT. IT REQUIRES AN APPLE 31 COMPUTER RUNNING DOS 3.3 WITH 48K OF RAM MEMORY.

THE LANGUAGE COMES WITH A FIFTY PAGE MANUAL AND OVER FORTY SCORES INCLUDING THE ORIGINAL 36 FROM FIRE ORGAN. THEY HAVE BEEN SPECIALLY COMMENTED BY THE COMPOSERS TO HELP YOU GET STARTED.

* ADD NOTHING FOR TAXES, POSTAGE, ! HANDLING, ETC, ANYWHERE IN THE USA !

VAGABONDO ENTERPRISES 1300 E ALGONQUIN - 36 SCHAUMBURG IL - 60195

(DIRECT MAIL ORDERS ONLY)

Putting S-C Assembler II on the Language Card . . Paul Schlyter [Paul is a subscriber in Stockholm. Sweden.]

Introduction

I have owned the S-C Assembler II for only a little more than three weeks, and already I have stopped using the two other assemblers I used to use before ("Apple Text Processing System" and "DOS Tool Kit Assembler"). Although the others have some powerful features, the S-C Assembler is so much easier to use it now takes me only about half the time to finish an assembly language program as it did before.

The many similarities between the S-C Assembler and Integer BASIC made me curious, so I disassembled the Assembler. Earlier I have done the same thing with Integer BASIC, Applesoft, and DOS. It wasn't too long (about a week) that I had a fair understanding of the first third of the assembler. Then the idea turned up in my head: "Why not try to relocate it into the language card?" Another week of sleepless nights and it was up and running!

There were several traps on the way. It took a long time for me to discover the address stack put into DOS at \$1333-133C. Sometimes I just entered the regular assembler at \$1000-24FF and didn't notice anything, sometimes the machine crashed when a DOS error occurred. But that was a week ago, and the last week nothing like that has happened...now I feel fairly confident that I have found all bytes that need to be relocated. If anything does turn up, I will let you know.

Why and How

Have you ever thought about how very similar to Integer BASIC the S-C Assembler II is? It stores its source files as DOS type-I files, and numbers the lines the same way as Integer BASIC. Just like in Integer BASIC, you have access to all DOS commands. Well, the similarities don't stop there. Integer BASIC starts at address \$E000 and ends a little bit above \$F400; the S-C Assembler starts at \$1000 and ends a little bit above \$2400. The byte at \$E000 is \$20 in Integer BASIC (JSR opcode) while it is \$4C in Applesoft (JMP opcode); it is by looking at this byte that DOS decides whether Integer BASIC or Applesoft is the current language. Well, guess what the byte at \$1000 in the S-C Assembler is: it's \$20!

When putting all these facts together, I started to wonder if it wasn't possible to relocate the S-C Assembler up into the Language card, making DOS believe it is in Integer BASIC. This of course requires that you have Applesoft on the motherboard ROMs, so that DOS will be able to distinguish between the ROM and Language card languages.

Sure enough, it is possible. I did move it up there, and it works, and it turned out to be really convenient. The DOS

command FP puts me in Applesoft, while INT puts me into the S-C Assembler! Also, if I am currently in Applesoft and LOAD an S-C Assembler source file (type-I, of course), DOS will automatically start up the assembler! Can you really ask for more?

To relocate the S-C Assembler into the language card, you need of course a language card (any of the several RAM cards no available will do). You also need to have Applesoft in ROM on the motherboard (not Integer BASIC). You also need a relocation program; I used the one in the Programmer's Aid \$1 software, which is in the INTBASIC file on the DOS 3.3 System Master. You could use the one in Bob Sander-Cederlof's article elsewhere in this AAL just as well.

Step-by-step Procedure

- 1. Boot the DOS 3.3 System Master. This will load Integer BASIC into the Language Card.
- 2. Type INT to enter Integer BASIC.
- 3. Put in the S-C Assembler II disk, and BLOAD ASMDISK 4.0 (do not BRUN it).
- 4. Enter the Apple monitor by typing CALL -151. (Throughout the following steps, be sure you do NOT hit RESET!)
- 5. Now that you are in the monitor. type the following commands:

C083 C083 (write-enable the language card)

D4D5G (initialize the relocation program)

E000<1000.24FF^Y* (specify source and destination blocks for the relocation program.

Note that "^Y" means "control-Y".

The asterisk at the end IS necessary.)

E000<1000.100E^Y (relocate the first segment)

.100FM .121E^Y .1282M .1330^Y .133CM .1436^Y

.1438M .147C^Y .14A9M .14DB^Y .141EM .14F3^Y

.14F5M .15D0^Y .15D6M .17A6^Y .17AEM .1A8C^Y

.1A91M .1BB7^Y .1CAEM .2149^Y .2150M .221C^Y .24FFM

(The monitor commands on the above four lines relocate the program segments and move the data segments. They can be typed as shown, or one per line. or even all on one line. Just be sure to type them correctly -- check and double check -- before pressing RETURN.)



Get your computer projects on track fast. Start with the Index.

You want to start a computer project but you don't know where to begin. You know there's piles of information out there. But you don't have the time to dig through the mess. Start with the Index. And get on track, fast.

Over 30,000 Entries

Over 6 Years of Articles, Editorials & Columns Written on Personal Computers

References from Over 800 Issues of Personal Computer Magazines

Over 45 Publications

Publications Like Byte, Kilobaud Microcomputing and Apple Orchard

SEE YOUR LOCAL COMPUTER DEALER or

Order from:

MISSOURI INDEXING, INC.

P.O. Box 301 St. Ann, Mo. 63074 (314) 997-6470 6. The machine code relocator automatically updates any direct address references in the program being relocated. This saves us a lot of work, but it does not finish the work. We also have to fix all the address tables and all immediate address references. Enter the following monitor commands to fix all of these (only one command per line):

| E042:E2 | E254:E2 | E334:E0 | F234:F1 |
|---------|---------|---------|---------|
| E227:E7 | E259:EB | E336:E0 | F239:F0 |
| E22C:E5 | E25E:E3 | E338:E0 | F23E:F0 |
| E231:E0 | E263:E0 | E33A:E3 | F243:F0 |
| E236:E5 | E268:E5 | E33C:E0 | F248:F2 |
| E23B:E1 | E26D:F1 | E4A3:E4 | F24D:F0 |
| E240:E4 | E272:E6 | E83E:F2 | F252:F1 |
| E245:E1 | E277:E1 | F225:F0 | F257:F0 |
| E24A:E6 | E27C:E0 | F22A:F1 | F25C:EE |
| E24F:E3 | E281:EB | F22F:F0 | F261:E0 |

7. The cold start routine in the Assembler must be patched:

E030:ED E2

E2E0:AD 83 C0 AD 83 C0 A9 00 85 D9 4C 08 E3 AD 83 C0

E2F0:AD 83 C0 4C 75 E3

8. If you wish, you may change the starting address of the Assembler Symbol Table to make more space:

E011:10

E2D6:10

9. If you enter Applesoft from the S-C Assembler, the output hook from DOS will still be connected to the S-C Assembler output routine. But the assembler will be banked away since now the motherboard ROMs are enabled! The result is that the Apple will hang. To cure this problem, you will have to sacrifice the SLOW and FAST commands, and the ability to suspend/abort listings using the space bar and RETURN keys. This is not such a big sacrifice anyway, since all language card owners have the Autostart Monitor: you can use control-S to suspend a listing. You can also use RESET to abort one (provided your language card has a switch and it is in the UP position). [If you can't bear to part with SLOW and FAST, you can type FP and then hit RESET to get out of the Assembler.]

Here are the patches to eliminate SLOW and FAST:

Ele9:EA EA EA EA

E22D:4D 4E 54 68 FF

E273:FF FF FF

These patches also change FAST to MNT, a command that gracefully enters the monitor. From the monitor, a control-C will re-enter the S-C Assembler with the current source program intact; a control-B will cold start the S-C Assembler.

10. Save the completed package on disk with:

BSAVE LANGASM, A\$E000, L\$2000.

11. Modify a copy of the HELLO program from the DOS 3.3 System Master Disk to BLOAD LANGASM instead of INTBASIC, and use this as your HELLO program. When you boot it will automatically load the S-C Assembler II into your language card.

Parting Shots

Maybe you think that I must have a thorough knowledge of how the S-C Assembler II works internally to be able to do this relocation, but this is not actually the case. I made a disassembly and also hex and ASCII dumps of the whole assembler, and I also started to untangle the code, but I only really know about a third of the code fairly well. I still have not the faintest idea of how the actual assembly is performed, although looking at the ASCII dump immediately revealed where the opcode and command tables were located, and the error messages. I also did find out the places where the error messages are produced...this helps a lot in figuring out what is happening in the code. And with this not-too-well understanding of the inner workings, and with a lot of trial-and-error, I was able to find all the places where changes needed to be made.

My S-C Assembler has been running from my language card for over a week, and I have used it a lot during this time; all has gone very well. And believe me, it is SO CONVENIENT to have it there! I really benefit from the language card, not only when using Pascal or CP/M, but also when I am running DOS. And I use the S-C Assembler II much more than Integer BASIC, so having the assembler in the language card is really the right thing for me. Maybe it is for you too!

So, Bob, although you have made an excellent and very easy to use assembler. it is not quite true anymore that the S-C Assembler II is the easiest assembler to use...LANGASM is. And as you have guessed, LANGASM is nothing but the S-C Assembler II relocated into the language card!

[If the instructions for making LANGASM leave you breathless, you can order Quarterly Disk \$6 (\$15.00). It will include all the source code from this issue and the next two of AAL, and also an EXEC file which will create LANGASM from ASMDISK 4.0. It will be ready in early March, 1982. Another shortcut is to order the source code of the S-C Assembler II (\$95.00). Then simply change the origin, modify the SLOW and FAST commands, and re-assemble it. Voila! LANGASM!]

Now that I have my Firmware card with Integer BASIC on it plugged into slot 4, I am all too frequently needing to fix those two bytes in DOS. For some reason I don't get around to putting the patched DOS onto every disk. But with a few EXEC files I can make the patches very easily now.

The first EXEC file, which I call INT, is like this:

CALL -151 (get into the monitor)
CO81 (turn off the language card, if on)
COC1 (turn off the firmware card, if on)
A5B8:CO (patch DOS to use firmware card)
A5C0:Cl
3D3G (return to DOS and Applesoft)
INT (enter Integer BASIC)

The second file I use to load LANGASM into the Language Card (see Paul Schlyter's article elsewhere in this issue of AAL). Here is what it looks like:

CALL-151 (get into the monitor)
COC1 (turn off the firmware card, if on)
CO81 CO81 (write enable the language card)
BLOAD LANGASM (load LANGASM into the language card)
A5D8:80 (patch DOS to use the language card)
A5C0:81
3D3G (return to DOS and Applesoft)
INT (enter the assembler)

The third EXEC file I use to patch DOS back to its normal mode of using the language card in slot 0. If I have already loaded the S-C Assembler II (LANGASM) into that card, but was using Integer BASIC, EXEC ASM will get me back to the assembler.

CALL-151 (get into the monitor)
CO81 (turn off the language card, if on)
COC1 (turn off the firmware card, if on)
A5B8:80 (patch DOS to use the language card)
A5C0:81
3D3G (return to DOS and Applesoft)
INT (enter the assembler)

Just for fun, here is one more EXEC file. This one copies the contents of the firmware card in slot 4 into the language card in slot 0. A much faster way of loading it with Integer BASIC than running HELLO on the DOS 3.3 System Master!

CALL-151 (get into the monitor)
COCO (turn on the firmware card)
1000<D000.FFFFM (copy firmware card into mother RAM)
COC1 (turn off the firmware card)
CO81 C081 (write enable language card)
D000<1000.3FFFM (copy stuff into the language card)
3DOG (return to DOS)

If you don't have an editor that will help you build EXEC files like these, here is a short Applesoft program which will do it. I have also included a short program to display the file, in case you need to do that.

Both of these programs CALL 64874. which is the Apple Monitor subroutine to read a line into the system buffer starting at \$200. The CALL -3288 in READ EXEC FILE is to fix the ONERR stack pointer.

```
100 REM WRITE EXEC FILE
130 D$ = CHR$ (4): INPUT "FILE NAME: ";F$
140 PRINT D$"OPEN"F$: PRINT D$"DELETE"F$
150 PRINT D$"OPEN"F$: PRINT D$"WRITE"F$
160 GOSUB 500: IF PEEK (512) = 175 AND PEEK (513) = 170 AND PEEK
(514) = 141 THEN 220
170 I = 511
180 I = I + 1:C = PEEK (I): PRINT CHR$ (C);: IF C < > 141 THEN
          180
190
         GOTO 160
          PRINT D$"CLOSE"
220
230
500
          END
         REM INPUT A LINE WITHOUT DOS KNOWING
IN# 0: PR# 0: CALL 64874: CALL 1002: RETURN
505
100
        REM READ EXEC FILE
       D$ = CRR$ (4): INPUT "FILE NAME: ";F$
PRINT D$"NOMONCIO": PRINT D$"OPEN"F$: PRINT D$"READ"F$
ONERR GOTO 220
CALL 64874
I = 511
I = I + 1:C = PEEK (I): PRINT CHR$ (C);: IF C < > 141 THEN
130 D$ =
140
150
160
170
          180
190
          GOTO 160
                    - 3288: PRINT D$"CLOSE"
220
          CALL
```

6500/1 One-Chip Computer......Dan Pote

Commodore Semiconductor Group has announced a new one-chip microcomputer, called the 6500/l. (I believe the same chip is available from Synertek and Rockwell.) The 6500/l has a 6502 CPU and is compatible with existing 6502 programs. There are also four I/O ports (32 bi-directional lines, the equivalent of two 6522 devices), a counter, 2048 bytes of ROM, and 64 bytes of static RAM. Your choice of 1- or 2-MHz internal clock. It can be ordered as masked-ROM, PROM, or piggy-back EPROM. For more information call Commodore at (214) 387-0006.

A New Compiler.....Bobby Deen

For about 3 months now I have been using test versions of a new compiler from Laumer Research. The compiler is called FLASH! and compiles Integer Basic programs into fast machine language programs. The machine code will execute 12 times faster than Integer Basic and the speed increase gets even greater on larger programs.

This compiler unlike all others on the market today has the ability to produce not only binary machine code but will make assembly language listings and files. Complete with labels for line numbers, forward references, variables, and runtime package entry points. All assembly language is compatable with the S-C Assembler II syntax and the file format is the familiar 'I' type DOS file ready to assemble with the runtime package!

This does save time in the development of machine language programs! A program which might take 2 weeks of your time to develop in assembly language, can be done in 2 hours in basic then compiled to get the speed benifit of machine language. If you have the runtime source code option you can take an assembly language file that the compiler can produce and, using the S-C Assembler, you can edit the inner loops of you program to gain even more speed or add new assembly language modules of your own!

The runtime package I keep referring to is the collection of subroutines which support the compiled code by providing commonly used functions such as routines to multiply and divide numbers, string handling functions, and input/output routines. The runtime package is self contained and does not require Integer Basic to allow a compiled program to execute (hark ye software authors!). The compiled code will even execute on a cassette based system if you ask FLASH! to put the runtime code into the code file with your compiled program. FLASH! will not normally include the runtime package in your output file to conserve your valuable disk space. Instead it will use a standard runtime package that runs from \$800-\$1BFF and is loaded by a short loader placed at the beginning of the output file.

FLASH! will compile every normal Integer Basic statement except the statement "LIST" which is ignored by FLASH!. FLASH! also has 28 new statements and 3 new functions which provide DATA, READ, HPLOT, DRAW, XDRAW, CHR\$, 16 bit PEEK's and POKE's, hex input and output abilities, hex strings of almost any length (to free memory size), and more to provide almost everything that could be of use in a systems programming language.

I have a hires graphics program which generates mazes that I have wanted to code in machine language for some time now. In Basic the program takes about 12 minutes to run. I go to high school during the daytime and I am in the school band. After school I have two part time jobs to take up most of the rest of my time. So its been hard to find time to convert the program to machine language with so little spare time.

Once I got a test version of FLASH! and compiled the maze program it would draw a maze in 1.25 minutes! A dramatic increase in program speed. Using the assembly language file output by FLASH! I recoded some of the code more efficiently and got the maze program to run in 55 seconds! Now it almost takes longer to print the maze on my printer than it does to run the compiled version of the maze program.

The FLASHI compiler is so easy to use that I have been using it for three months before the preliminary reference manual was printed. FLASHI will keep track of a compilation by status fields on the bottom line of the Apple II screen. Since a compilation can take several minutes the status information is handy to have. I think that the FLASHI compiler is one of the slickest programs in my program library and really compliments the S-C Assembler II. I plan much use for it in the future.

Here is an example of the code produced by the FLASH! compiler.

for the basic statements :

- 10 A=3
- 20 B=-1000*A
- 30 PRINT B/(A+2)

the following code is created by FLASH! :

| 1C00- | | | | | .OR | \$1C00 | program origin |
|---------|-----|-----|----|---------|------------|--------------|----------------------------|
| | | | | | .IN | R.RUNTIME LO | ADER |
| 1C1E- 2 | 20 | 63 | OA | L.START | JSR | R.INIT | initialize runtime package |
| 1021- (| 00 | 00 | | | .DA | LINE.TBL | line number table address |
| 1023- (| 00 | 00 | | | .DA | LINE .TBLN | number of entries |
| 1025- (| 00 | 00 | | | .DA | DATA.TBL | data statement table |
| 1C27- (| 00 | 00 | | | .DA | DATA.TBLN | number of entries |
| 1029- 1 | 78 | 1C | | | .DA | DSP.VAR.TBL | begining of DSP variables |
| 1C2B- 7 | 7D | 1C | | | .DA | END. VARS | end of all variables |
| 1C2D- 7 | 7D | 1C | | | .DA | FREE.P | free memory pointer |
| 1C2F- 8 | 83 | 79 | | | .DA | FREE.S | size of free memory |
| 1031- 0 | 00 | | | | .HS | 00 | flag for error routine |
| 1C32- I | A9 | 03 | | L.10 | LDA | #3 | lo byte of constant 3 |
| 1C34- I | AO. | 00 | | | LDY | /3 | hi byte of constant 3 |
| 1C36- 8 | 8D | 79 | 1C | | STA | A | store lo byte of A |
| 1C39- 8 | 8C | 7 A | 1C | | STY | A+1 | store hi byte of A |
| 1C3C- / | A9 | 18 | | L.20 | LDA | #-1000 | load lo byte of -1000 |
| 1C3E- / | A O | FC | | | LDY | /-1000 | load hi byte of -1000 |
| 1C40- 2 | 20 | 39 | 09 | | JSR | R.PSH | push -1000 on stack |
| 1C43- I | AD | 79 | 1C | | LDA | A | get lo byte of A |
| 1C46- I | AC | 7 A | 1C | | LDY | A+1 | get hi byte of A |
| 1049- 2 | 20 | 9B | 09 | | JSR | R.MUL1 | multiply -1000*A |
| 1C4C- / | A9 | 7B | | | LDA | #B | lo adrs of B |
| 1C4E- 1 | AO. | 1C | | | LDY | /B | hi adrs of B |
| 1050- 2 | 20 | 2B | 13 | | JSR | R.ASG.VAR | save value into B |
| 1053- 1 | AD | 7B | 1C | L.20 | LDA | В | load lo byte of B |
| 1C56- I | AC | 7C | 1C | | LDY | B+1 | load hi byte of B |
| 1059- 2 | 20 | 39 | 09 | | JSR | R.PSH | push value of B on stack |
| | | | | | | | |

| 1C5C- AD 79 1C LDA A load lo byte | OI A |
|---|----------------|
| 1C5F- AC 7A 1C LDY A+1 load hi byte | of A |
| 1C62- 20 39 09 | f A on stack |
| 1C65- A9 02 LDA #2 get lo byte | of 2 |
| 1C67- A0 00 LDY /2 get hi byte | of 2 |
| 1C69- 20 48 09 | |
| 1C6C- 20 D0 09 | +2) |
| 1C6F- 20 2B 12 | |
| 1C72- 20'8E FD JSR MON.CROUT print car re | tn |
| 1C75- 4C B9 OD JMP R.NOEND go to NOEND | error |
| LINE.TBL .EQ 0 no table bec | ause no GOTO's |
| LINE.TBLN .EQ 0 with express | ions on them |
| DATA.TBL .EQ 0 no table bec | ause no |
| DATA TBLN .EQ 0 data stateme | nts |
| 1C78-00 DSP.VAR.TBL .HS 00 end of DSP v | ariables |
| 1079- A .BS 2 2 byte value | of A |
| 1C7B- B .BS 2 2 byte value | of B |
| 1C7D- END. VARS end of varia | ble area |
| 1C7D- FREE.P start of fre | e memory |
| FREE.S .EQ 31107 size of free | memory |
| 1C7DEN end of code | |

FLASH! an Integer BASIC Compiler

by Laumer Research 1832 School Rd. Carrollton. Texas 75006

- Compiles Integer BASIC to fast Machine language which runs on any Apple II or Apple II Plus, disk or cassette, 16k to 48k with or without Integer BASIC.
- 28 new statements and 3 new functions to extend the language including DATA, READ, hex I/O, strings to 32767 bytes, 16-bit PEEKs and POKEs, CHR\$, HOME, NORMAL, INVERSE, HPLOT, DRAW, XDRAW and much more!
- * Makes BRUN files positioned anywhere you want in memory.
- Assembly language listing and file output compatible with S-C Assembler II!

Introductory price \$65.00 for FLASH! compiler, \$20.00 for runtime package source code. (Prices good until May 1, 1982) (Source code requires S-C Assembler II 4.0 and FLASH!)

FLASH! can be used on a 48k Apple II or Apple II Plus with Integer BASIC in ROM or language card. Runs under DOS 3.3 on one disk drive.

Apple Assembly Line is published monthly by S-C SOFTWARE, P. O. Box 280300, Dallas, Texas 75228. Phone (214) 324-2050. Subscription rate is \$12 per year in the U.S.A., Canada, and Mexico. Other countries add \$12/year for extra postage. Back issues are available for \$1.20 each (other countries add \$1 per back issue for postage). All material herein is copyrighted by S-C SOFTWARE, all rights reserved. Unless otherwise indicated, all material herein is authored by Bob Sander-Cederlof. (Apple is a registered trademark of Apple Computer, Inc.)

Page 24....Apple Assembly Line....January. 1982....Copyright (C) S-C SOFTWARE